

Tools & Materials Required

- Schneller Non-Textile Flooring (e.g. AerMat, PanFlor)
- Sharp Razor Knife
- Straight Edge
- Industrial or all-purpose floor cleaner
- Small Hand Squeegee
- Double Face Tape:
There are a variety of double-faced tapes on the market:
 - Polyken 108 - Flame retardant double-faced tape is available from Tyco Adhesives. More information can be obtained by calling Tyco at 1-800-343-7875 or by visiting their website at www.tycoadhesives.com.
 - Orcotape OT-40 is a double-faced, reinforced polyester tape available from the Orcon Corp. More information can be obtained by calling 1-800-227-0505 or by visiting their website at www.orcon.com.
- OPTIONAL: Template of aircraft floor
- OPTIONAL:
 - A 3M™ Polyurethane protective tape, designated #8671, has been successfully used as a moisture barrier. This protective film is a durable thermoplastic elastomer with an acrylic pressure sensitive adhesive. Further information on this product can be obtained from 3M™ by phone at 1-800-362-3550 or by visiting their website at www.3M.com.
 - Polyvinyl chloride film, designated P-306L, available from Permacel®. Further information can be obtained on this product by calling 1-800-755-TAPE or by visiting their website at www.permacel.com.
- Sealant:
A Silicone sealant that can be used to seal edges and custom color-matched to the Schneller NTF is Schneller AerSeal™.

Fitting of Schneller Non-Textile Flooring

- Remove all trim and thresholds where necessary. Schneller Non-Textile Flooring may be installed under doors, lavatories, galleys, entryways and closets to aid in floor retention and sealing.
- Measure, cut and fit a template in the area to be covered. This is an optional step but may aid in the application of Schneller Non-Textile Flooring.
- Use the template and cut the Schneller Non-Textile Flooring to size using a sharp razor knife. Many times it is better to leave an extra 1-2 inches and finish trimming the Schneller Non-Textile Flooring to exact size in the aircraft.

Data and information provided free of charge by Schneller, Inc. for corporate and/or educational informational purposes only. The information provided is believed to be accurate, but Schneller and its suppliers do not warrant or guarantee such accuracy. Schneller expressly assumes no responsibility for the accuracy or usefulness of information provided by any third party data or content provider. Schneller shall have no obligation to update or otherwise supplement or correct any data provided. Neither Schneller nor any of its data or content providers shall be liable for any errors or delays in the content, or for any actions taken in reliance thereon.

Preparation of Floor

- Clean floor with industrial strength floor cleaner.
- Allow floor to dry well, making sure that all moisture is removed before installation of the Schneller Non-Textile Flooring.
- Vacuum floor to remove all grit and dirt ensuring a clean bonding surface.

Application of Optional Moisture Barrier

- Cut and fit the moisture barrier to the designated area.
- Peel off the protective paper backing on one end for approximately 4-6 inches and start adhering to the floor with a squeegee.
- Continue peeling the paper backing from the moisture barrier and squeegee to the floor until completed.

Application of Double-Faced Tape

- Apply a double-faced tape on the cleaned floor (or moisture barrier). This can be applied at a minimum of around the perimeter and every four inches across the application area. To ensure a uniform bonding surface, it is possible to also apply the double-faced tape to the entire surface.

Installation of Schneller Non-Textile Flooring

- Beginning with the center of the area, peel off the protective layer from the double faced tape over half of the area to be covered.
- Carefully lay the Schneller Non-Textile Flooring in place beginning in the center of the application area and slowly apply pressure into the tape and around the edges.
- Remove the remaining protective paper from the double faced tape and complete the lay-in process beginning in the center and working outward.

Re-Installation

- When re-installing either the threshold or joint strips, care must be taken to fill the gaps between the strips and the Schneller Non-Textile Flooring with a sealant. This is suggested in order to minimize the likelihood of liquids seeping through the joint and becoming trapped between the Schneller Non-Textile Flooring and aircraft floor boards.
- A sealant should also be used along the edges of the Schneller Non-Textile Flooring to seal liquids from migrating and becoming trapped under the flooring.

Data and information provided free of charge by Schneller, Inc. for corporate and/or educational informational purposes only. The information provided is believed to be accurate, but Schneller and its suppliers do not warrant or guarantee such accuracy. Schneller expressly assumes no responsibility for the accuracy or usefulness of information provided by any third party data or content provider. Schneller shall have no obligation to update or otherwise supplement or correct any data provided. Neither Schneller nor any of its data or content providers shall be liable for any errors or delays in the content, or for any actions taken in reliance thereon.